

.....


.....

PROXERSAFE®, KEYSAFE® - EXPANSION OPTIONS

Think ahead. Order your ProxerSafe®, Keysafe® Lock cabinet in a larger capacity cabinet house for a later expansion.

CHOOSE THE SIZE YOU CURRENTLY NEED

Key capacity can be determined by 8 and 16 key holder plugs. Standard key module - called KSM16 - guards 16 keys. (You may order "half module", so only 8 keys in one module. Half module can later be replaced with a full capacity KSM16.)





CHOOSE CABINET FOR THE CAPACITY AND OPTIONS YOU MAY NEED IN THE FUTURE

Think ahead and order ProxerSafe® in a larger house for a later expansion!

We provide the cabinet with the keyholder capacity you currently need, and fill up the cabinet house unit with blank modules.

You can easily and quickly replace blank modules with KSM16 modules on site.

Basic modules of housing units are 32, 64, 112 and 160.



DO YOU WANT TO EXTEND CAPACITY BUT HAVE NO FREE SPACE IN THE CABINET? DO YOU NEED MORE THAN 160 KEYS?

Extension cabinet units, so-called slave units. can be ordered. The new units will use the master cabinet's controller.



IF YOU ALSO NEED BOXES, CHOOSE A DEEPER CABINET HOUSE

Basic model of KeySafe® Lock cabinets is 15 cm deep.

Cabinets are also available in other depths, like 20 cm, 30 cm or 45 cm.







EXAMPLES FOR EXTENSIONS

KSL16/32

One KSM16 and a blank module in the cabinet house of a KSL32. It can be extended with an extra KSM16 key module for the total capacity of 32 keys on site.





KSL32/64

Two KSM16 modules and two blank modules in the cabinet housing of a KSL64. It can be extended with two extra KSM16 key modules for the total capacity of 64 keys on site.





KSL80/112

Five KSL16 modules and two blank modules in the housing of a KSL112. It can be extended with two extra KSM16 key modules for the total capacity of 112 keys on site.





YOU MAY NEED BOXES IN THE FUTURE?

Extend your ProxerSafe® system with a SLave cabinet

You may order a slave cabinet with boxes beside your existing KeySafe Lock key cabinet.

KeySafe Lock 96, the master cabinet with the built-in computer, contains six KSM16 modules.

The additional slave ProxerSafe® Box cabinet has 56 S-size boxes with metal doors.



Extend your ProxerSafe® system with additional cabinets, integrated into the existing system

Cabinets can form a company network, e.g. via TCP / IP Ethernet network. You may choose "Stand-alone operation with local and central synchronised databases" or "Operation managed from a central server" operation mode.



KSL64



PSB-32BS



PSB-24BSG-4BMG



PSB-2B4M-4BL

PROXERSAFE® COMBO CABINETS WITH KEY MODULS AND BOXES

EXAMPLES



PSC-32K-16BS



PSC-16K-8BS-4B2S-2B4S



PSC-16K-24BS



PSC-16K-4BM-2B2M-1B4M

EXAMPLES OF EXPANSION MODULES



KSM16: module with 16 RFID key



8BSG: 8 S-size boxes with security glass doors (with metal frame)



8BS: 8 S-size boxes with metal doors



4BMG: 4 M-size boxes, glass door (with metal frame)



4BMT: 4 M-size boxes, metal door



2B4SG: 2 "4S"-size boxes, glass doors



2B4S: 2 "4S"-size boxes, metal doors



4BL: 4 x L size box, metal door



4BLP: 4 L-size boxes, plexiglass doors

PROXERSAFE® COMBO DEMO

